

# IOT Made Simple: Playing With the ESP32 on Arduino IDE



Let's explore in this tutorial, the ESP32, the fantastic newer Development Kit board for IoT use. This board, developed by Espressif, should be the NodeMCU's successor, due to its low price and great features.

But is also important to point that NOT ALL libraries or functions that you are used to working with ESP8266 and/or Arduino are yet functional on this new board. Probably this will be soon, so check it regularly on ESP 32 Forum WebPage.

Here we will learn how to program the ESP32 on Arduino IDE, exploring its most common functions and libraries, point some of the important differences and new features introduced with this great chip.



# Step 1: The ESP32 Main Characterictics

The ESP32 is an under US\$10 board with great advantages over similar IoT boards in the market.

This board has a dual processed microprocessor that helps a lot, because when one processor is handle communication, the other one is in charge of I/O control, for example. This feature will prevent some issues that happen with ESP8266, where the sole CPU needs stop controlling I/Os when handle with Comm. Besides, the ESP32 has integrated WIFI, BLUETOOTH, DAC, several ADC (not only one as the ESP8266), capacitive touch

sensors, etc (give a look at above block diagram). And the good news is that Power Consumption is almost the same as ESP8266.

Bellow a chart that can show us its main characteristics, and differences when compared with ESP8266:

Specifications	ESP8266	ESP32	
MCU	Xtensa® Single-Core 32-bit L106	Xtensa® Dual-Core 32-bit LX6 600 DMIPS	
802.11 b/g/n Wi-Fi	Yes, HT20	Yes, HT40	
Bluetooth	None	Bluetooth 4.2 and below	
Typical Frequency	80 MHz	160 MHz	
SRAM	160 kBytes	512 kBytes	
Flash	SPI Flash , up to 16 MBytes	SPI Flash, up to 16 MBytes	
GPIO	17	36	
Hardware / Software PWM	None / 8 Channels	1 / 16 Channels	
SPI / I2C / I2S / UART	2/1/2/2	4/2/2/2	
ADC	10-bit	12-bit	
CAN	None	1	
Ethernet MAC Interface	None	1	
Touch Sensor	None	Yes	
Temperature Sensor	None	Yes	
Working Temperature	- 40℃ ~ 125℃	- 40'C ~ 125'C	

Let's point its main properties in more details:

### Key Features:

- 240 MHz dual core Tensilica LX6 microcontroller with 600 DMIPS
- Integrated 520 KB SRAM
- Integrated 802.11 b/g/n HT40 Wi-Fi transceiver, baseband, stack and LwIP
- Integrated dual mode Bluetooth (classic and BLE)
- 16 MB flash, memory-mapped to the CPU code space
- 2.3V to 3.6V operating voltage
- -40°C to +125°C operating temperature
- Onboard PCB antenna / IPEX connector for external antenna

### Sensors:

- Ultra-low noise analog amplifier
- Hall sensor
- 10x capacitive touch interfaces
- 32 kHz crystal oscillator

### 34 x GPIO:

- 3 x UARTs, including hardware flow control
- 3 x SPI
- 2 x I2S
- 18 x ADC input channels
- 2 x DAC
- 2 x I2C
- PWM/timer input/output available on every GPIO pin
- OpenOCD debug interface with 32 kB TRAX buffer
- SDIO master/slave 50 MHz
- Supports external SPI flash up to 16 MB
- SD-card interface support

### Security Related:

- WEP, WPA/WPA2 PSK/Enterprise
- Hardware accelerated encryption: AES/SHA2/Elliptical Curve Cryptography/RSA-4096

### Performance:

- Supports sniffer, Station, SoftAP and Wi-Fi direct mode
- Max data rate of 150 Mbps@11n HT40, 72 Mbps@11n HT20, 54 Mbps@11g, and 11 Mbps@11b
- Maximum transmit power of 19.5 dBm@11b, 16.5 dBm@11g, 15.5 dBm@11n
- Minimum receiver sensitivity of -97 dBm
- 135 Mbps UDP sustained throughput
- 5 A power consumption in Deep-sleep



# Step 2: BoM - Bill of Material

- ESP32 Dev Kit: ESP32 Development Board (US\$ 8.52)
- LED
- Resistor: 330 ohm
- Potentiometer: 10K ohm
- Protoboards

### Step 3: ESP32 Arduino IDE Installation

We will use the Arduino IDE to program our ESP32, same way we do with the ESP8266 family.

#### Install Drivers:

It is important that you have installed on your computer, the updated CP210x USB to UART Driver. Enter in this link: usb-to-uart-bridge-vcp-drivers and install the proper driver for your OS.

#### Install Library:

The novelty here is that Expressif itself in its GitHub, will give us the proper directions for library installation: arduino-esp32. Follow the instructions for your OS. In my case (MacOS), the installation is very simple:

Open Terminal and execute the following command (copy->paste and hit enter):

```
mkdir -p ~/Documents/Arduino/hardware/espressif && \
cd ~/Documents/Arduino/hardware/espressif && \
git clone https://github.com/espressif/arduino-esp32.git esp32 && \
cd esp32/tools/ && \
python get.py
```

After that, restart Arduino IDE and it's done! You must see several boards on "TOOLS" Menu. Select the appropriate for you. In general, the "generic" ESP32 DEV MODULE works fine.

When you open the Arduino IDE for the first time, you will note that the default upload speed is 921,600 bauds. This can provoque instability. **Change it to 115,200 bauds**!



# Step 4: Hello World! Blinking a LED

As usual, the first thing to do when we start exploring a new HW is to blink a LED.

Go to **Examples Menu** in the IDE and open the Blink sketch.

The ESP32 DevKit, has a built-in LED that is connected to its GPIO 02. It is important to check if "*LED\_BUILTIN*" is automatically recognized by IDE. If not, you must add to code the line:

```
int LED_BUILTIN = 2;
```

Each ESP32 board has an internal LED connected to a different GPIO



Below the internal LED blinking (note the blue light) together with an external one connected to GPIO 2:

$\searrow$		$\times$
á.		>>
		$\langle \rangle \rangle$
	ESP\$2 Blink	
$\times$	XXXXXX	

There are several different boards with different pin maps in the market. The above diagram shows the board that I am using. You can find it here: /ESP32-Development-Board

Perfect! So, **DigitalWrite()** is working perfectly, same way with ESP8266 and Arduino. BTW, **DigitalRead()** also works the same way to read a digital input, like a push-button for example.

### Step 5: The Touch Sensor

Let's jump to a new cool feature, the Touch Sensor!

The ESP32 has 10 internal capacitive touch sensors. You can use it as buttons for example.

Those sensors are connected with several GPIOs:

- T0: GPIO 4
- T1: GPIO 0
- T2: GPIO 2
- T3: GPIO 15
- T4: GPIO 13
- T5: GPIO 12
- T6: GPIO 14
- T7: GPIO 27
- T8: GPIO 33
- T9: GPIO 32

In order to read them you must use the function: *touchRead(Touch Pin #);* 

For example, to read the Touch Sensor 0 (T0), you must do something like:

int value = touchRead(4);

Let's create a code, where if we touch the sensor T0 (GPIO4), the LED will be on.

Use the serial monitor to check the values read by the sensor and adjust the code properly.

Below the complete code:



#### And below the ESP32 working:





# Step 6: Analog Input

Let's now test how to Input analog value signals.

There are in total 18 x 12 bits ADC input channels, versus only 1 X 10bits ADC on NodeMCU.

p.p1 {margin: 0.0px 0.0px 0.0px 0.0px; font: 12.0px 'Helvetica Neue'; color: #454545} span.Apple-tab-span {white-space:pre}

GPIO ADC Channel

- GPIO 0 ==> ADC2\_CH1
- GPIO 2 ==> ADC2\_CH2
- GPIO 4 ==> ADC2\_CH0
- GPIO 12 => ADC2\_CH5
- GPIO 13 => ADC2\_CH4
- GPIO 14 => ADC2\_CH6
- GPIO 15 => ADC2\_CH3
- GPIO 25 => ADC2\_CH8
- GPIO 26 => ADC2\_CH9
- GPIO 27 => ADC2\_CH7
- GPIO 32 => ADC1\_CH4
- GPIO 33 => ADC1\_CH5
- GPIO 34 => ADC1\_CH6
- GPIO 35 => ADC1\_CH7
- GPIO 36 => ADC1\_CH0
- GPIO 37 => ADC1\_CH1
- GPIO 38 => ADC1\_CH2
- GPIO 39 => ADC1\_CH3

To read the analog input, you will the same as have done with Arduino and ESP8266:

int analog\_value = analogRead(36);

It's very important to note that, the ESP32 ADCs have 12bits of resolution (versus 10bits on ESP8266 and Arduino), so the total range of ADCs reading go to 4,095 (instead 1,027 on Arduinos and ESP8266) when a maximum of 3.3V is applied to its inputs.

For input, let's use a 10K ohm potentiometer, connecting it from 3.3V and GND. Let's use its variable output to be the input for ESP32 ADC pins. The Above diagram shows the potentiometer connected to GPIO 36 that is the ADC1 Channel 0. Try also other inputs on your board.

Run the simple code below:

fr



Turn your potentiometer and observe on IDE Serial Monitor the measurements going from zero to 4,095.

	• • •	/dev/cu.SLAB_USBtoUART	
			Send
	ESP32 Analog IN Test 0 0 0 9 336 642 968 1179 1366 1620 1856 1865 2389 2939		Send
330Ω	3283 4095 4095 4095		
itzing	Autoscroll	Both NL & CR 🔋 115200 baud	Clear output

# Step 7: Dimming a LED: Analog Output Using PWM

If we want to "Dimmer a LED" on ESP8266 or an Arduino, we can simply use a command like *analogWrite()*, that IOT Made Simple: Playing With the ESP32 on Arduino IDE: Page 9

will vary the PWM value of its output, simulating an analog value. Unfortunately, we still do not have such kind of command developed for the ESP32 on Arduino IDE. but the very good news is that all 36 of ESP32 GPIOs has a PWM capability, what is great! Only we must use more complex code to reach the same result.

So, let's program one of that GPIOs with a PWM output signal.

You can find a very good tutorial in details about how PWM works at this link: esp32-arduino-led-pwm-fading.

The first thing to think about a PWM signal to be generated is its frequency. We will use a value of 5000 Hz, that works fine with the LED. We must also specify the LED PWM channel and the resolution of the PWM duty cycle, in bits. We can choose a channel from 0 to 15 and a resolution between 1 and 16 bits. We will use channel 0 and a resolution of 8 bits.

int freq = 5000; int ledChannel = 0; int resolution = 8;

Let's use GPIO2, where we have our external LED attached (and the internal one).

#define LED\_PIN 2

Those parameters must be defined during setup() phase, using below functions:



To turn on the LED with a specific brightness, we must define the "duty cycle".

For example, to turn off the LED, the duty cycle must be zero and the function *ledcWrite(ledChannel, dutyCycle)* used to send the value thru a specific PWM channel:

```
int dutyCycle = 0;
ledcWrite(ledChannel, dutyCycle);
```

Different values of the dutyCycle variable will turn on the LED with different brightness. this variable, dutyCycle, will vary from 0 to 255, once the resolution used is 8 bits.

We can use the Potentiometer (connected to *analog\_value* variable) to manually setup the dutyCycle variable, but once their range of values are different, let's use a map function to match input and output:

dutyCycle = map(analog\_value, 0, 4095, 0, 255);

Below the complete code:

```
********
* ESP32 Analog Input/Output Test
* Analog Input: ADC_1_0 pin ==> GPIO36 (VP).
* PWM LED pin ==> GPIO 02
* MJRoBot.org 6Sept17
//Analog Input
#define ANALOG_PIN_0 36
int analog_value = 0;
// PMW LED
#define LED_PIN 2
int freq = 5000;
int ledChannel = 0;
int resolution = 8;
int dutyCycle = 0;
void setup()
{
 Serial.begin(115200);
 delay(1000); // give me time to bring up serial monitor
 Serial.println("ESP32 Analog IN/OUT Test");
 ledcSetup(ledChannel, freq, resolution);
 ledcAttachPin(LED_PIN, ledChannel);
 ledcWrite(ledChannel, dutyCycle);
}
void loop()
{
 analog_value = analogRead(ANALOG_PIN_0);
 Serial.println(analog_value);
 dutyCycle = map(analog_value, 0, 4095, 0, 255);
 ledcWrite(ledChannel, dutyCycle);
 delay(500);
}
```

#### That's it!





### **Step 8: Servo Control**

Let's control a Servo Motor using the PWM capability of our ESP32. The code will be basically the same one that was used to control the LED brightness.

First, it's important to remember that the frequency to work with a Micro Servo is 50Hz, so we must change the frequency parameter to 50 (instead of 5,000 used with LED). We must also specify the LED PWM channel and the resolution of the PWM duty cycle, in bits. We will use again channel 0 and a resolution of 8 bits.

int freq = 50; int channel = 0; int resolution = 8;

The Servo will be connected to GPIO 5 (see above electrical diagram).

#define SERVO\_PIN 5

Same as with LED, those parameters must be defined during setup() phase, using below functions:

void setup()
{
ledcSetup(channel, freq, resolution);
ledcAttachPin(SERVO_PIN, channel);
}

To position the servo on a specific angle, we must define the "duty cycle" (please, see the above diagram).

For example, to position the servo around 90 degrees, the duty cycle must be around 21 and the function *ledcWrite(ledChannel, dutyCycle) should be* used to send the value thru the PWM channel:

int dutyCycle = 21; ledcWrite(channel, dutyCycle);

Different values of the dutyCycle variable will position the servo with different angles. This variable, dutyCycle,

IOT Made Simple: Playing With the ESP32 on Arduino IDE: Page 12

should vary from 10 to 32 (this range was gotten manually).

Same as we did with the LED, the Potentiometer (connected to *analog\_value* variable) can be used to manually setup the dutyCycle variable and so, changing the servo position. Once their ranges of values are different, let's use a map function to match input and output:

dutyCycle = map(analog\_value, 0, 4095, 10, 33);

#### Below the complete code:

```
* ESP32 Servo Control
* Analog Input: ADC 1 0 pin ==> GPIO36 (VP).
* PWM SERVO pin ==> GPIO 05
* MJRoBot.org 6Sept17
//Analog Input
#define ANALOG_PIN_0 36
int analog_value = 0;
// PMW SERVO
#define SERVO_PIN 5
int freq = 50;
int channel = 0;
int resolution = 8;
int dutyCycle = 21;
void setup()
{
 Serial.begin(115200);
 delay(1000); // give me time to bring up serial monitor
 Serial.println("ESP32 Servo Control");
 ledcSetup(channel, freq, resolution);
 ledcAttachPin(SERVO PIN, channel);
 ledcWrite(channel, dutyCycle);
}
void loop()
{
 analog_value = analogRead(ANALOG_PIN_0);
 Serial.print(analog_value);
 Serial.print(" Duty Cycle ==> ");
 Serial.println(dutyCycle);
 dutyCycle = map(analog_value, 0, 4095, 10, 33);
 ledcWrite(channel, dutyCycle);
 delay(50);
}
```

Now we can work with the Ultrasonic Sensor on top of the servo and build an IoT Radar!. But this will be another tutorial! ;-)





fritzing

# Step 9: Connecting to Internet: Local Time Stamp

After testing some of the GPIO digital/analog and input/output capabilities, let's connect our ESP32 on the internet!

With ESP8266 family we were using the library *esp8266wifi.h* for that. With the ESP32, the library to use will be:

<wifi.h>

A very simple example would be programming our board to capture from the internet the local time. This is a very good feature to have on hand on projects. The below code will do it for us:

/*************************************
#include <ntpclient.h> #include <wifi.h> #include <wifiudp.h></wifiudp.h></wifi.h></ntpclient.h>
#define NTP_OFFSET -3 * 60 * 60 // In seconds #define NTP_INTERVAL 60 * 1000 // In miliseconds #define NTP_ADDRESS "europe.pool.ntp.org"
WiFiUDP ntpUDP; NTPClient timeClient(ntpUDP, NTP_ADDRESS, NTP_OFFSET, NTP_INTERVAL);
<pre>void setup() {    Serial.begin(115200);    timeClient.begin(); }</pre>

You can see at Serial monitor the local time being stamped.

	/dev/cu.SLAB_USBtoUART		
			Send
03:28:17			
03:28:19			
03:28:21			
03:28:23			
03:28:25			
3:28:27			
3:28:29			
3:28:31			
3:28:33			
3:28:35			
3:28:37			
3:28:39			
3:28:41			
3:28:43			
3:28:45			
Autoscroll	Both NL & CR	115200 baud	Clear output

### Step 10: Simple WiFi Server

Let's now test our ESP32 as a simple WiFi Server.

• Open the EXAMPLES menu on your Arduino IDE and get the ESP32 WiFi/SimpleWiFiServer.ino sketch:

About this program:

- Created for arduino 25 Nov 2012 by Tom Igoe
- Ported for sparkfun esp32 31.01.2017 by Jan Hendrik Berlin

A simple web server that lets you blink an LED via the web. This sketch will print the IP address of your ESP32 WiFi network to the Serial monitor. From there, you can open that address in a web browser to turn on and off the LED on pin 5.

If the IP address of your board is for example 10.0.1.40:

- <u>http://10.0.1.40/H</u>turns the LED on
- <u>http://10.0.1.40/L</u>

turns the LED off

This example is written for a network using WPA encryption. For WEP or WPA, change the Wifi.begin() call accordingly.

Circuit: LED attached to pin 5

So, let's use the program without significant modifications. Change the External LED Pin to GPIO5

Off course, if you prefer change the code for GPIO2 w/o changing the HW.

First, enter your network credentials:

```
const char* ssid = "yourssid";
const char* password = "yourpasswd";
```

And upload it on your ESP32.

The first thing that you will see at your serial Monitor will be the information that your ESP32 is connected and what is its Ip Address:

WiFi connected. IP address: 10.0.1.40

Open your favorite browser, typing this IP address. You will get a WebPage like the one above. There you can Turn on or off the LED remotely.



 ● ●
 ⊡ 10.0.1.40/H
 ×
 MJRoBot

 ← → C ☆
 ① 10.0.1.40/H
 Q ☆
 ≅
 I ⊆
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≅
 I ≦
 I ≦
 I ≦
 I ≦
 I ≦
 I ≦</t

Click <u>here</u> to turn the LED on pin 5 on. Click <u>here</u> to turn the LED on pin 5 off.

# Step 11: Conclusion

We can go on and on here. There is a lot left to explore on ESP32. So, let's stop for a moment and think about that. I will return soon with new tutorials.

As always, I hope this project can help others find their way in the exciting world of electronics, robotics, and IoT!

Please visit my GitHub for updated files: NodeMCU Dual Temp Monitor For more projects, please visit my blog: MJRoBot.org

Saludos from the south of the world!

See you at my next instructable!

Thank you,

Marcelo

